## **Assembly Instructions**

## **LCC-222 Side Table**



## **Required Tools:**

- Hammer
- Cordless Drill
- #2 Square Drive Bit
- 7/16" Wrench or Socket

## Hardware:

- (8) 2 1/2" Screws
- (4) 1/4" x 3 1/2" Bolts
- (4) 1/4" Flange Nuts



**Step 1**Lay table (A) upside down on a soft surface and attach 4 legs (B) in positions shown with (8) 2 1/2" screws. Notice: left & right.



Complete!



**Step 2** Attach shelf (C) as shown with (4) 3 1/2" bolts & nuts.



www.wildridge.com 330-893-4212