


Disconnect the battery grounds before installation to avoid accidentally arc'ing the line on the glow plug relay or the alternator charging lug. Use pictures from the product webpage for routing example. The fittings are marked with numbers to match installation location (see below for reference). After installation, be sure there are no other lines/wires that are touching the lines that could potentially rub through and damage either the HPOP line or the other line that may be touching it. Use a small section of wire loom protector or a larger piece of rubber hose to wrap around the contact point. Many will remove or bend the engine eyelet on the driver side as a precaution, but it is not necessary. Sealant is not necessary, but **IF** you choose to use any, use Loctite 680 or Permatex 64000 retaining compound (green) only on the fittings installed in the HPOP. If you are unsure of installing yourself, seek out a competent and qualified technician to install the lines.

HOSE IDENTIFICATION: 98.5-03 2 LINE-BOTH SIDES ARE SAME LENGTH. 94.5-97 2 LINE-PASSENGER IS LONGER OF THE 2. **FOR ANY 3 LINE KIT THE SHORTEST LINE IS THE CROSSOVER HOSE.

FITTING MARKINGS: 1- FRONT PUMP PORT 2- REAR PUMP PORT 3- DRIVER HEAD 4- 94.5-97 PASSENGER HEAD 5- 98.5-03 PASSENGER HEAD AND CROSSOVER **94.5-97 driver side fitting gets moved forward one port on the head to match 98.5-03**

Pump Fittings: 28FT/LBS • Head Fittings: 23FT/LBS • Hose Ends: 21FT/LBS *REMOVE THE SPRING CHECKS IN THE PUMP UNDER THE STOCK FITTINGS, DO NOT RE-INSTALL*

94.5-97 HOSE ROUTING EXAMPLES (424001-424002)



98.5-03 HOSE ROUTING EXAMPLES (424003/424004)

