



Mounting Instructions

1. Only 1 bolt hole needs to be used.
2. Wire the relay according to the wiring diagram.

This diagram is for a Trombetta relay made for Western/Fisher snow plow pump motors. To avoid any mistakes on where to place the wires, remove the wire(s) one terminal at a time and install wire(s) on the new relay. Large eyelet wires on large posts, small wire eyelets on small posts.

****DISCONNECT MAIN BATTERY GROUNDS BEFORE REMOVING OLD RELAY AND DO NOT RECONNECT BATTERY GROUNDS UNTIL AFTER NEW RELAY IS INSTALLED**