



Rear face to firewall

This side faces driver

**Installation Note: LHD MR2 AW11 Chassis**

1. Install pedal adapter to firewall and secure bolts labeled (1 & 2) first. (Torque: 12nm)
2. Install throttle pedal TOY: 78110-33020 using bolts and nuts labeled (3 & 4) (Torque: 12nm)

**Warning:**  
Do Not Trap Carpet or other material between firewall and pedal adapter

Dept.	Technical reference	Created by	Approved by	
Material: ABS		Document type	Document status	
		Title	DWG No.	
		<b>Throttle Pedal Adapter 72001-23002 Rat2 Motorsports</b>		
Rev.	Date of issue	Sheet		
AA	2/27/2020	1/1		