

# ROCKET JACKPOINT INSTALLATION

1. *Remove main wheel assy. Including Brake Caliper.*
2. *On the inboard forward side of your wheel pant mounting bracket , Align your Jackpoint Base mount as shown in the photo ensuring the Jacking Arm insert bolt is touching the shown portion of your wheel pant bracket. This will give you the proper setting to mark and drill the 1/4" mounting holes.*
3. *Drill the 1/4" mounting holes, deburr and install the Jackpoint base mount using supplied screws & nuts*
4. *File a CLEARANCE slot on your wheel pant bracket where the arm bolt needs to clear for installation of the Arm bolt as shown in the photos*
5. *You may need to realign your brake line to your Caliper for clearance for ARM install . We recommend the Scissors Jack and Alum floor Jack from Harbor freight. Part numbers SKU#66907 & 62160*

