

## Safe Jack

dba of Bogert Manufacturing Inc

3606 N Swallow Ave Ste 200 Pasco, WA 99301

(509) 735-2106 Phone (800) 627-8088 Toll Free (509) 272-0280 Fax

www.SafeJacks.com

**Model Number: 51M-USF** 

PN: 51106

This 51M-USF is easily attached to the jack with a wire bale clevis pin. This foot will replace any foot that is too large( larger than 7 inches X 4 inches) to fit into our base plate .This foot should fit virtually all of the Hi-Lift brand jacks and all of the imported jacks of this type.



Part Number	Model Number	Description
51106	51M-USF	Universal Hi-Lift Replacement Steel Foot
_37R250PWQ0Z	37R250PWQ0Z	3/8 x 2 1/2 Wire Lock Pin Square Zinc

- 1. Remove existing cotter pin or screw from foot of Hi-Lift Jack.

  Remove Jack from Foot.
- 2. Attach our Universal Steel Foot to your Hi-Lift Jack using the Square Wire Lock Pin. (The foot should extend forward under the lifting member of the Jack.)



## Hi-Lift Jack Not Included

## Universal Hi-Lift Replacement Steel Foot

