

HEAVY DUTY BRACKET

INSTALLATION INSTRUCTIONS



STEP 1 Mark a level line across the wall where the piece will be hung. This mark should be run at a height that should be close to the middle of your mantel. This is **IMPORTANT** to note because when you mount your mantel, the top of the mantel will be higher than that line and the bottom will be lower.

PLEASE NOTE: If you need it at a specific height you will need to determine how far it is from the top of your mantel to the center of the bracket.

STEP 2 Mark the **CENTER POINT** of the mantel on the level line.

STEP 3 On the **BACK** of the mantel, make a mark at the center of the mantel and follow the mark down to the bracket (should be inserted in the back of your mantel).

STEP 4 Mark where your studs are located on the wall.

STEP 5 Now line your bracket mark up with your center mark on the wall and using the level line as a guide and the marked stud locations.

STEP 6 Secure the bracket to the wall using screws into the studs. If your screw head is too small for the slot in the bracket, we recommend using a washer to prevent the screwhead from penetrating all the way through the bracket.

STEP 7 Slide shelf/mantel over the brackets.

STEP 8 Check for level and adjust accordingly.

IMPORTANT: Please use common sense! We recommend you contact a local professional for additional mounting help if you are not familiar with tools!



Modern Timber Craft
401 E 4th St, Building 20
Bridgeport, Pennsylvania 19405

(866) 999-6635
info@moderntimbercraft.com
www.moderntimbercraft.com