

# Step 'n Wash Installation Instructions

## See enclosed install template for diagram

To ensure both proper installation and compliance with local building codes, it is necessary that a qualified person or licensed installer perform the installation of the product.

When properly installed, the product has been tested to support a static load of up to 800 lbs. To achieve this rating, 3/8" diameter stainless steel anchor bolts (supplied) must be secured into a concrete subfloor. Finished floor assemblies that exceed 1" in thickness will require the installer to use 3/8" diameter stainless steel anchor bolts that are longer than those supplied. For other subfloors such as wood, consult with the project architect for appropriate blocking diagram and recommendation of alternative fasteners.

- 1 Remove from the shipping container and inspect for any damage. Handle with care to avoid scratching.
- 2 Identify the best location for installing the unit. Using the enclosed template as a guide, locate and mark the four mounting holes on the floor. Note: the front mounting holes must be a **maximum of 6"** and a **minimum of 5 1/2"** from the front edge of the sink or counter. **After marking the mounting holes and BEFORE drilling the mounting holes, position the unit on top of the mounting hole marks to ensure that the front of the unit does not break the front plane of the sink or counter.**
- 3 Using a hammer drill and a 3/8" diameter carbide-tipped masonry bit, drill each mounting hole approximately 2 1/2" deep into the floor. Drill the mounting holes straight down, and do not move the drill from side-to-side while drilling; doing so will result in mounting holes that are too wide to properly support the anchors.  
**\*Using a 1/8" bit to first drill a pilot hole will minimize the chance of chipping or cracking floor tile\***
- 4 Remove all debris from within each hole and clean the floor around where the unit will be mounted.
- 5 Place each of the four wedge anchors into the mounting holes and hammer the anchors until approximately 3/4 " of the anchor remains exposed.
- 6 Push and twist the four sealing washers (black side down) over each of the four exposed anchors. Note: washers fit snug.
- 7 Position the unit on top of the anchors. Next, place a washer and nut over each of the four anchors and turn each nut until the unit is snug. Fully tighten all anchor nuts to secure the unit to the floor.
- 8 Caulk around the base of the unit where it meets the floor. This will prevent dirt and water from becoming trapped beneath the unit.
- 9 Remove backing and apply "Parents:" decal to restroom mirror.
- 10 Check to make sure that the hex bolts on each side of the unit are fully tightened.

Once installed:

- 1 Test product to ensure stability, workmanship, and safety
- 2 Inspect and maintain product on a weekly basis
- 3 Immediately uninstall product if broken, damaged, or defective

