



**Replacing the original fan in a P9000/P12000  
with the 3" boxer fan part# 01-042**

1. Undo 2 screws – 1 each side – located at the bottom of the unit to disconnect the bottom cover plate. Remove the cover.
2. Undo the knot holding the black and red power wires together
3. Unscrew the screws holding the fan in place
4. Disconnect the red wire from the rheostat (speed control) and remove fan from unit
5. Connect red wire of the new fan on the rheostat to the same tab that you just removed the old one from.
6. Attach new fan using screws and washers provided. Make sure the washers go between the fan bracket and the unit.
7. Tie the black wire from the fan and the red wire from the on/off switch in a knot so that the knot will come below the bottom of the heater.
8. Replace the bottom cover making sure to thread the red and black wires through the white grommet hole on the bottom.

