



841 S. 71st Avenue • Phoenix, AZ 85043
(623) 907-0081
www.performanceaccessories.com

GAP GUARD INSTALLATION INSTRUCTIONS.

⚠WARNING

Read and understand all instructions, warnings, cautions, and notes in this sheet before you begin gap guard installation.

Always wear eye protection when operating power tools.

⚠NOTE

No two vehicles have holes spaced identically. If you are stretching a hole on the gap guard too much, punch another hole with a 1/4" paper punch. Most stock guards mount from the inside, but our gap guards mount from the outside. Kit parts are prefaced by the word *kit* in italics.

A. Before you start.

1. Read all warnings and instructions completely and carefully before you begin.
2. Check to make sure the kit is complete (refer to the Parts List).
3. Only install this kit on the vehicle for which it is intended.
4. Park the vehicle on a clean, dry, flat, level surface and block tires so the vehicle cannot roll in either direction.

B. Install the kit.

1. To install this kit you will need:

- Drill
- 1/4" drill bit

2. Front.

⚠NOTE

Gap Guards each mount with the matted side outward.

- a. Locate *kit* gap guard marked #####-1.
- b. At driver side front wheel well, position *kit* gap guard to cover side of engine compartment.
- c. Mark a top hole and drill if necessary with a 1/4" drill bit.
- d. Install *kit* plastic fastener through *kit* gap guard and into the wheel well.
- e. Check alignment and mark next hole while keeping *kit* gap guard snug.
- f. Proceed with steps d. and e. until *kit* gap guard is installed
- g. Repeat steps b. through f. for front passenger side/*kit* gap guard marked #####-2.

3. Rear.

⚠NOTE

Gap Guards each mount with the matted side outward.

- a. Locate *kit* gap guard marked #####-3.
- b. At driver side rear wheel well, position *kit* gap guard in wheel well and mark first hole to be drilled.
- c. If necessary drill hole with 1/4" drill bit, insert *kit* plastic clips through *kit* gap guard and press into hole in wheel well.
- d. Realign *kit* gap guard in wheel well, mark and drill the next hole. Insert *kit* plastic clips.
- e. Repeat steps c. and d., keeping *kit* gap guard snug.
- f. Repeat steps b. through e. for rear passenger side *kit* gap guard marked #####-4.

C. Kit Parts List.

Qty	Description
1	Driver front gap guard (#####-1)
1	Passenger front gap guard (#####-2)
1	Driver rear gap guard (#####-3)
1	Passenger rear gap guard (#####-4)
1	Package plastic clip fastener