



WARNING
READ THIS BEFORE INSTALLING
FAILURE TO COMPLY WITH THESE
INSTRUCTION MAY CAUSE SERIOUS
INJURY OR DEATH

We recommend the following

- 1) that the seat be mounted to the roll cage or structural member of the frame
- 2) That you bolt the seat in six (6) places
 - a. Four(4) on the seat bottom
 - b. Two (2) just below the shoulder belt holes as wide as possible

We DO NOT recommend the use of stock sliders and adjusters as these can let go in a high impact crash.