

350 S. St. Charles St. Jasper, In. 47546 Ph. 812.482.2932 Fax 812.634.6632 www.ridetech.com

Part # 11053699 58-64 Impala Front Upper StrongArms

Components:

1	90000478	Passenger side Upper Arm						
1	90000479	Driver side Upper Arm						
2	90000905	Ball Joints (includes boot, grease fitting, castle nut & cotter pin)						
4	90000907	Cross shaft bushing						
2	90000927	Upper Cross Shaft						
		. 05						
Hard	Hardware:							
4	99371014	3/8"-24 x 1 1/4" Gr. 8 bolt Upper cross shaft						
4	99373001	3/8" x 1 1/2" washer Upper cross shaft						
		3/8"-24 x 1 ½" Gr. 8 bolt Upper cross shaft 3/8" x 1 1/2" washer Upper cross shaft						

Hardware:

4	99371014	3/8"-24 x 1 1/4" Gr. 8 bolt	Upper cross shaft
4	99373001	3/8" x 1 1/2" washer	Upper cross shaft




Installation Instructions



- 1. Drop the ball joint down through the ball joint plate, secure w/ the hardware supplied.
- 2. Fasten the upper arm to the frame using the factory hardware. Reinstall the current alignment shims, but **vehicle must be realigned.** This arm was designed with an extra 2 degrees of positive caster allowing the car to be aligned with up to 4 degrees of positive caster. (This will vary from car to car.)
- 3. Insert the ball joint stud through the spindle and install new castle nut and cotter pin supplied.

58-64 Impala <u>Driver</u> Side Upper StrongArm – Top View



STRONGARMS by Air Ride Technologies

Item #	Description	Qty.
1.	Passenger side arm	1
1.	Driver side arm	1
2.	Cross shaft bushing	4
3.	Cross shaft	2
4.	Ball joint	2
5.	5/16"-24 x 1" hex bolt	6
6.	3/8"-24 x 1 1/4" hex bolt – Gr. 8	4
7.	3/8" x 1 1/2" washer	4
8.	5/16" lock washer	6
9.	5/16"-24 hex nut	6

