



350 S. St. Charles St. Jasper, In. 47546
Ph. 812.482.2932 Fax 812.634.6632

www.ridetech.com

Part #11343699
63-70 C-10 Front Upper StrongArms

Components:

- | | | |
|---|----------|--------------------------------------|
| 1 | 90000508 | Driver side upper arm |
| 1 | 90000509 | Passenger side upper arm |
| 2 | 90000721 | Cross shaft |
| 2 | 90000920 | Cross shaft kit – 2 bushings per kit |
| 2 | 90000911 | Upper ball joint |

Hardware:

- | | | | |
|---|----------|--------------------------------|-------------|
| 2 | 99753002 | 3/4" flat washer (2" diameter) | Cross shaft |
| 2 | 99752003 | 3/4" SAE locking nut | Cross shaft |



STRONG ARMS™

by Air Ride Technologies

Installation Instructions



1. Drop the ball joint down through the upper control arm plate. Fasten to the arm w/ the hardware supplied.
2. Fasten control arm to frame using the stock hardware. Reuse the alignment shims; however the truck must be realigned after installation.
3. Slide the ball joint boot over the stud, then insert stud through spindle. Secure w/ new castle nut and cotter pin supplied.
4. **With the suspension at mid travel**, the upper cross shaft nuts can be tightened.
5. Install Zerk fitting and grease ball joint.