

ASSEMBLY INSTRUCTIONS

FOR

WILWOOD INTERNAL PARKING BRAKE CABLE KIT FOR USE WITH WILWOOD BRAKE KIT 140-11900

2011 - PRESENT FORD FIESTA

PART NUMBER GROUP

330-11936

**DISC BRAKES SHOULD ONLY BE INSTALLED BY SOMEONE
KNOWLEDGEABLE AND COMPETENT IN THE FUNCTIONING
AND MAINTENANCE OF DISC BRAKES
READ ALL WARNINGS**

WARNING

IT IS THE RESPONSIBILITY OF THE PERSON INSTALLING ANY BRAKE COMPONENT OR KIT TO DETERMINE THE SUITABILITY OF THE COMPONENT OR KIT FOR THAT PARTICULAR APPLICATION. IF YOU ARE NOT SURE HOW TO SAFELY USE THIS BRAKE COMPONENT OR KIT, YOU SHOULD NOT INSTALL OR USE IT. DO NOT ASSUME ANYTHING. IMPROPERLY INSTALLED OR MAINTAINED BRAKES ARE DANGEROUS. IF YOU ARE NOT SURE, GET HELP OR RETURN THE PRODUCT. YOU MAY OBTAIN ADDITIONAL INFORMATION AND TECHNICAL SUPPORT BY CALLING WILWOOD AT (805) 388-1188, OR VISIT OUR WEB SITE AT WWW.WILWOOD.COM. USE OF WILWOOD TECHNICAL SUPPORT DOES NOT GUARANTEE PROPER INSTALLATION. **YOU**, OR THE PERSON WHO DOES THE INSTALLATION MUST KNOW HOW TO PROPERLY USE THIS PRODUCT. IT IS NOT POSSIBLE OVER THE PHONE TO UNDERSTAND OR FORESEE ALL THE ISSUES THAT MIGHT ARISE IN YOUR INSTALLATION.

RACING EQUIPMENT AND BRAKES MUST BE MAINTAINED AND SHOULD BE CHECKED REGULARLY FOR FATIGUE, DAMAGE, AND WEAR.



WARNING

**DO NOT OPERATE ANY VEHICLE ON UNTESTED BRAKES!
SEE MINIMUM TEST PROCEDURE WITHIN**

ALWAYS UTILIZE SAFETY RESTRAINT SYSTEMS AND ALL OTHER AVAILABLE SAFETY EQUIPMENT WHILE OPERATING THE VEHICLE

IMPORTANT • READ THE DISCLAIMER OF WARRANTY INCLUDED IN THE KIT

NOTE: Some cleaners may stain or remove the finish on brake system components. Test the cleaner on a hidden portion of the component before general use.

Important Notice - Read This First

Before any tear-down or disassembly begins, review the following information:

- Due to OEM production differences and other variations from vehicle to vehicle, the fastener hardware and other components in this kit may not be suitable for a specific application or vehicle.
- It is the responsibility of the purchaser and installer of this kit to verify suitability / fitment of all components and ensure all fasteners and hardware achieve complete and proper engagement. Improper or inadequate engagement can lead to component failure.
- We recommend using an anti-seize lubricant on all aluminum nuts before tightening.

Parts List

<u>ITEM NO.</u>	<u>PART NO.</u>	<u>DESCRIPTION</u>	<u>QTY</u>
1	330-11898	Parking Brake Cable - Driver and Passenger Side	2

General Information

- Installation of this kit should only be performed by individuals experienced in the installation and proper operation of disc brake systems. Prior to any attempt to install this kit, please check the following to ensure a trouble free installation.
- Inspect the contents of this kit against the parts list to ensure that all components and hardware are included.
- If you have any questions, please call our customer service department at (805) 388-1188. Additional information is available on our web site at www.wilwood.com.

Disassembly Instructions

Remove the Original Equipment Manufacturer's (OEM) parking brake cables:

- Raise the rear wheels off the ground and support the rear suspension according to the vehicle manufacturer's instructions.

FROM INSIDE THE VEHICLE:

- Be sure parking brake lever is released (off) inside the vehicle.

FROM UNDERNEATH THE VEHICLE:

- **NOTE:** Make note of the existing cable routing. The Wilwood cables will be installed along the same path.
- Detach OEM cables from rear drums.
- At the balance bar, detach the OEM cables from the bulkhead and balance bar (in the tunnel).
- Remove and save the brackets holding the original cables to the chassis, Photo 1. They will be reused on the new cables.
- Remove both left and right side cables (do not remove the balance bar, it will be reused with the Wilwood cable kit).



Photo 1. Remove and Save the OE Brackets

Assembly Instructions

IMPORTANT:

- To ensure maximum performance from your parking brake system, the cables must be routed as straight as possible. Bends in the cable can significantly reduce efficiency and thus reduce pull force at the brake. Tight bends must be avoided with a minimum recommended bend radius of 6" to 8".
- Cables should be properly restrained to prevent "straightening" of bends when tension is applied. Restrain movement of cable by affixing the cable sheath to body or chassis by fitting cable clamps at various points over the length of cable or by using original equipment cable attachments points. The clamping method chosen will require that cable sheath be held tightly without movement, crushing or causing interference to the internal cable.
- Cables must be initially pre-stretched by multiple applications of the brake handle, then re-adjusted to correct tension.

FROM UNDERNEATH THE VEHICLE:

- Install Wilwood CPB brake kit per its instructions.
- Install the OEM brackets over the Wilwood cable in the same position that they were removed from the original cables, Photo 1.
- Attach E-clip end of the new cable to the caliper, as shown in Photos 2 and 3. Ensure that the E-clip is fully engaged into its groove.
- Route new cable in the same location as the OEM cable, from balance bar to the caliper. **Carefully route cable to prevent contact with exhaust or moving suspension, brake or wheel components.** *NOTE: it's the installer's responsibility to properly route and ensure adequate clearance and retention for parking brake cable components.*
- The balance bar connector slots/holes that secure the new Wilwood cable must be "pryed" open slightly wider to accommodate the larger size diameter Wilwood cable, Photo 4.
- Attach the other end of the new cable to the balance bar assembly, Photo 5. Adjust the cable in the bulkhead so it is approximately centered in its adjustment range.
- Repeat the above steps for the other side cable.
- Attach OEM brackets, that were slipped over the new cables, in their original mounting holes.
- Tighten all bracket bolts and hardware.

SETTING THE PARKING BRAKES:

- The CPB caliper is a self-adjusting unit, it will require the installer to do the initial adjustment as outlined below.



Photo 2. Installation of Cable to Wilwood Combination Parking Brake Caliper



Photo 3. Installation of Cable to Wilwood Combination Parking Brake Caliper

Assembly Instructions (Continued)

FROM INSIDE THE VEHICLE:

- Apply light to moderate pressure on the brake pedal and hold.
- Cycle the parking brake lever on and off until the caliper adjusts to the rotor until it no longer gets tighter.
- After bleeding and bedding the brakes per the brake kit installation instructions, carefully test the holding power of the parking brakes. Test parking brake in a safe area, first on a flat surface by pushing on the vehicle, then on a slight incline by applying and releasing handle multiple times.
- For the best results always put pressure on the brake pedal as you set the parking brake.




Photo 4.

Pry Open the Balance Bar Connector Slots/Holes




Photo 5.

Installation of Cables to Balance Bar End

Brake Testing

WARNING • DO NOT DRIVE ON UNTESTED BRAKES BRAKES MUST BE TESTED AFTER INSTALLATION OR MAINTENANCE MINIMUM TEST PROCEDURE

- Make sure pedal is firm: Hold firm pressure on pedal for several minutes, it should remain in position without sinking. If pedal sinks toward floor, check system for fluid leaks. DO NOT drive vehicle if pedal does not stay firm or can be pushed to the floor with normal pressure.
- At very low speed (2-5 mph) apply brakes hard several times while turning steering from full left to full right, repeat several times. Remove the wheels and check that components are not touching, rubbing, or leaking.
- Carefully examine all brake components, brake lines, and fittings for leaks and interference.
- Make sure there is no interference with wheels or suspension components.
- Drive vehicle at low speed (15-20 mph) making moderate and hard stops. Brakes should feel normal and positive. Again check for leaks and interference.
- Always test vehicle in a safe place where there is no danger to (or from) other people or vehicles.
- Always wear seat belts and make use of all safety equipment.