



Thank you for purchasing our 235 Litre Wood Effect Water butt.

Water butts can be installed either with a diverter which also acts as an overflow or with direct rainwater inlet and separate overflow. The benefit of a diverter is it also acts as the overflow, however the yield will depend on the diverter selected. The benefit of a direct inlet is that it allows all the water to be captured instead of a proportion, combining this with a leaf catcher allows visible and accessible maintenance.

The outlet on this tank is not pre-installed. Please use the tap and bulkhead supplied to install the tap to the required location.

The planter is not pre drilled and so must be drilled for drainage to suit the application.

Diverter installation

Please follow the instructions provided with the diverter. The level of the diverter connection to the water butt will depend on whether a lid or planters are being used. If planters are being used the diverter and tank connection will be fitted just below the planter base level. If the lid option is being used the diverter and tank connection will be in the top panel of the water butt.

Offset kit / overflow installation

To install the leaf catcher, simply drill a hole the same diameter as the leaf catcher spigot then place the leaf catcher in the hole and sit the downpipe in the leaf catcher (see image below).

To install the overflow, drill a hole the same diameter as the overflow (ensure that the overflow sits just below the access level as shown on the image below).

