



# THE CITY

## WATER GARDEN

INSTALLATION GUIDE

Ecosure  
Efills Ltd  
Unit 1  
Whiting Way  
Melbourn  
Hertfordshire  
SG8 6NA

Phone: 01763 261781  
Fax: 01763 268409  
Email: [sales@ecosure.co.uk](mailto:sales@ecosure.co.uk)  
Website: [www.ecosure.co.uk](http://www.ecosure.co.uk)



## THANK YOU

Thank you for buying the City Water Garden. We hope you will be completely satisfied with your purchase. This industrial strength product is guaranteed frost-proof and is made from UV stabilised polymer.



## SAFETY INSTRUCTIONS

The Ecosure City Water Garden must be sited on a flat, level base. For installation guidance, please watch the promotional video at [ecosure.co.uk](http://ecosure.co.uk)

- When fixing your tap or valve to the moulded outlets, use 4 or 5 layers of PTFE tape and DO NOT OVERTIGHTEN. Hand tighten only; do not use a spanner or wrench.
- When using any power tools, be aware of others around you and wear suitable PPE.

## PLANTER DRAINAGE

There is no drainage in the planter when this Water Garden arrives with you. This allows you to use water loving plants and keep it topped up in dry weather. Alternatively, holes can be drilled in the clear plug at the base of the planter to provide drainage. If you decide to do this, then some filtration material such as hessian can be placed over this plug to clear the water of debris without blocking the drainage holes.

## BOTTOM OUTLET

The bottom back outlet allows you to drain the water reservoir completely. It is sealed when it arrives in case you do not wish to use it. However a green plastic shut-off valve with hose connector is provided. Drill the plastic seal out and fit.

## INSTALLATION GUIDE

RAINWATER DIVERTERS MUST BE INSTALLED BELOW THE BOTTOM OF THE BOWL OF THE PLANTER.

- a. Position the water butt a maximum of 500mm from the rainwater downpipe.



- b. Using a 32mm hole-saw or spade bit, cut a hole just below the base of the planter bowl and insert the rubber seal.



- c. Fit the rainwater diverter to the downpipe according to the manufacturer's installation instructions.



- d. Trim the connecting pipe if required, and push one end on to the diverter. Push the other end through the seal fitted onto the tank. Lubricate if necessary.



- e. If, when fixing a tap to the raised outlet, the tap does not face downwards, use another layer of PTFE and try again. Do not use too much tape as this may damage the threaded outlet. Hand tighten only; do not use a spanner or wrench.

