

Correct Assembly of Agua Water Barrel Hose



1) Apply PTFE tape to the finer thread on the Adaptor Nipple & Screw into the Barrel.

(Note: Tape to be wrapped in a clockwise direction when end of thread is viewed to ensure that tape does not unwind when nipple is screwed in)



2) Screw the female end of the hose onto the coarser thread of the Nipple.

(Note: the female end of the hose is fitted with a rubber seal)



3) Screw the female end of the isolation valve onto the male thread of the Hose

(Note: the female end of the isolation valve is fitted with a rubber seal)