



## Tire Bead Breaker-2 Assembly Instructions

1. Slide pieces (B) over piece (A) and attach with 2 tension bolts.
2. Slide piece (C) inside the other end of pieces (2) and attach with 2 more tension bolts.
3. Insert piece (D) into piece (C) as shown, this is held in with a tension bolt as mentioned before as well as a 3/8 bolt going through and attaching with Nyloc nut.
4. Slide piece (F) over piece (D) and use 2 more tension nuts to hold piece (F) in correct position for your use.
5. Piece (H) attached inside the tabs of piece (6) with a 3/8-16 bolt and Nyloc nut.
6. Piece (G) slides over piece (H) and is held in position with 2 more tension bolts. Adjust this piece to meet your needs.
7. Piece (E) attaches to piece (G) with another 3/8 bolt and nut in the same manner as described in step 6.