

AFT FUSELAGE ROTATOR ASSEMBLY INSTRUCTIONS

the base assembly (A) and tighten the four Jam bolts.

2. Slip the vertical tube (B) onto the

base assembly and tighten the two jam bolts.

into the upper tube assembly (c) into the vertical tube (b). This will be where you will adjust the pivot height (should be the same height as the fwd unit) to accommodate the size of the fuselage.

4. Slide the tube assembly (G) into the axie assemble (F) and tighten the

Jam bolts.
5. Slide the axie into the upper tube assembly and lock into place with the T Jam bolt (i). Slide the lock collar (F) onto the axie and tighten the set screw.

6. Slide the "T" fitting (H) onto the tube assembly (J) and tighten the jam bolts.

7. Slide tube (K) Into (J). 8. (J) will slide into (G).

Caution: Make sure that all jamb bolts are tight before using the unit



Bogert Aviation bogert-av.com