

# SAM-U (JK) users guide.

## **IMPORTANT!!!**

**First and far most, it is imperative to implement safety measures by chocking the wheel, applying the emergency brakes, and if the vehicle is four wheel drive capable, engage the vehicle in 4WD mode.**

**Attaching the SAM-U to the factory front recovery hooks:**

- 1). Mount the SAM-U adaptor to the Hi-lift jack and secure the SAM-U adaptor by utilizing the provided locking.



- 2). Place the locking retainer key, flat side down onto the factory recovery hook as shown on the photo below



- 3). Slide the SAM-U adaptor over the locking retainer key, insert the clevis pin through the SAM-U and the locking retainer key, and secure the clevis pin in place with the wire clip. Making sure the jack is on a vertical position, your ready to jack the vehicle up.





### Attaching the SAM-U to the factory rear recovery hooks:

- 1). Using the hoop located on top of the SAM-U, attach the SAM-U to the rear recovery hook.



- 2). Mount the Hi-Lift jack onto the SAM-U, secure the jack to the SAM-U using the locking pin, Making sure the jack is in the vertical position, you are ready to jack the vehicle up.



