

INSTALLATION INSTRUCTIONS

CP030200325&326

[Fit BMW X3 & X4]

Thank you for purchasing our products! Please contact us for any issues!

Warning: To avoid locking yourself out, first set the password or fingerprint codes with the **SAFE DOOR OPEN** and test the operation of the lock before closing the safe door.

Part lists:

4 PCS Screws

Tools Needed:

Torx screwdriver

STEP 1 Empty the armrest box of any content.



STEP 2 Console safe



STEP 3 Remove the factory bolts in the bottom of the armrest box. Open the safe lid, put the console safe into the armrest box, and find the **two reserved holes** in the bottom of the safe.



STEPS 4 Ensure the reserved **holes** of the safe **line up** with the **holes** of the armrest box. **Hand the screws into the armrest box' holes via the reserved holes of the safe.** Use a wrench to tighten the factory bolts. **Don't over-tighten** the bolts, over-tightening will cause **damage** to the armrest box.



STEP 5 Enjoy your purchase! Contact us for any issue.

If you have any questions, welcome to contact us by email!

We will contact you within 24hours.

Thank you very much!