

INSTALLATION INSTRUCTIONS

CP030200087&CP030200335&CP030200344

[2014-2019 Chevrolet Silverado and GMC Sierra 1500, also 2015-2020 Chevrolet and GMC 2500,3500]

Thank you for purchasing our products! Please contact us for any issues!

Parts List:

- **4** Self Tapping Screws
- **1** Punching Cone

STEP 1 When you receive this product, we recommend that you should check the accessories before the instruction.

STEP 2 The combination should be set with the **DOOR OPEN** in order to test the lock combination effectively without locking yourself out.

STEP 3 Clear out the contents of the center console for now, including the factory mat at the bottom of the console.

STEP 4 Remove the neoprene padding from the inside of the safe.

STEP 5 Place the safe into the console compartment.

STEP 6 Using a **1/8 DRILL BIT** along with a drill, pre-drill pilot holes into the console compartment where the screws will be set.

- a. The screws will be set in the two holes on either side of the safe.
- b. Make sure to drill through until the drill hits metal.
- c. To make this process easier, mark the locations where the holes will be drilled, remove the safe, then drill the pilot holes into the console compartment.

STEP 7 If you removed the safe from **STEP 5**, reinsert the safe into the console compartment.

STEP 8 Secure the safe into the console compartment using the **4 SELF TAPPING SCREWS**, these screws are to be set into the pre-drilled pilot holes from **STEP 5**.

STEP 9 Tighten the bolts, **DO NOT OVER TIGHTEN, THIS COULD DAMAGE THE CONSOLE.**

STEP 10 Enjoy your purchase!

Tools Needed:

- Impact drill or Socket wrench
- 1/8 Drill Bit
- Phillips Head Drill Bit (optional)