

INSTALLATION INSTRUCTIONS

CP030200334

**[2015 to 2020 Chevrolet Suburban and Tahoe, and GMC Yukon, and Yukon XL/
2014 to 2019 Chevrolet Silverado and GMC Sierra 1500, also 2015 to 2020
Chevrolet and GMC 2500, and 3500]**

Thank you for purchasing our products! Please contact us for any issues!

Accessories list:

- 2 PCS Bolts
- 1 PC backup key

Tools Needed:

- Phillips Screwdriver
- Socket Wrench

Note 1 When you receive this product, we recommend that you should check the accessories before the installation.

Note 2 The fingerprint should be set with the **DOOR OPEN** to test the lock effectively without locking yourself out.

Safe installation:

STEP 1 Empty the armrest box including the factory mat at the bottom.

STEP 2 Pull out **2 PLASTIC FILE HOLDERS** on either side of the armrest box.

- a. These are removed by pulling outward on the center of the tab, then forward towards the front of the console.

STEP 3 Use a wrench to remove the **2 BOLTS** from the bottom of the armrest box.

STEP 4 Remove the padding from the bottom of the inside of the safe.

STEP 5 Set the safe into the armrest box.

- a. To ensure that the console is set in properly, make sure that the reserved holes at the bottom of the safe line up with the holes in the armrest box.

STEP 6 Insert the **BOLTS** into the armrest box through the reserved holes of the safe.

STEP 7 Use a wrench to tighten the bolts, **DO NOT over-tighten bolts, over-tightening will damage the console.**

STEP 8 Re-insert the 2 file holders that were removed in **STEP 2**.

STEP 9 Enjoy your purchase. Any issues please contact us.