

INSTALLATION INSTRUCTIONS

CP030200083

CP030200171

CP030200332

[2009-2018 Dodge Ram 1500,2500, &3500 and the 2019 1500 Classic]

Thank you for purchasing our products! Please contact us for any issues!

Parts List:

- 4 Self Tapping Screws
- Punching cone
- Phillips Screwdriver

STEP 1 When you receive this product, we recommend that you should check the accessories before the instruction.

STEP 2 The combination should be set with the **DOOR OPEN** in order to test the lock combination effectively without locking yourself out.

STEP 3 Clear out the contents of the center console for now, including the factory mat at the bottom of the console.

STEP 4 Remove the neoprene padding from the bottom of the inside of the safe for now.

STEP 5 Set the safe into the center console.

STEP 6 Using a drill or screwdriver, insert the **SELF TAPPING SCREWS** into the slots at the bottom of the safe. **DO NOT OVER TIGHTEN THESE SCREWS, THIS COULD DAMAGE THE CONSOLE.**

STEP 7 Enjoy your purchase!

Tools Needed:

- Impact drill or Socket wrench
- 10mm Socket bit