

INSTALLATION INSTRUCTIONS

CP030200096

CP030200203

[2021+ Ford Bronco with Full Floor Console]

Thank you for purchasing our products! Please contact us for any issues!

Parts List:

- 4 3/4" Self-Tapping Screws
- 4 Acorn Nuts
- 1 Open End Wrench

STEP 1 When you receive this product, we recommend that you should check the accessories before the instruction.

STEP 2 The combination should be set with the **DOOR OPEN** in order to test the lock combination effectively without locking yourself out.

STEP 3 Clear out the contents of the center console for now, including the factory mat at the bottom of the console.

STEP 4 Place the 2 side brackets so that the bottom lip sits on the bottom lip of the console compartment

STEP 5 Insert the 2 studs on the underside of the top frame into the appropriate slots on the side bracket, then guide this side bracket out to the console wall. While continuing to hold the top frame, position the other side bracket to line up the remaining studs with the remaining slots, and drop the top frame into place

STEP 6 Open the door on the top frame, then thread the **Acorn Nuts** onto the studs on the underside of the top frame by hand

STEP 7 Using the **Open-End Wrench**, fasten the **Acorn Nuts** until they all contact the underside of the hinge plate features and **STOP! WARNING! OVERTIGHTENING THE NUTS WILL CAUSE DAMAGE TO THE THREADS.**

STEP 8 Using an impact drill with a Phillips head attachment or a Phillips head screwdriver, secure the two side brackets to the bottom of the console compartment using the **4 Self-Tapping Screws.**

STEP 9 Tighten the bolts, **DO NOT OVER TIGHTEN, THIS COULD DAMAGE THE CONSOLE.**

Tools Needed:

- Impact drill or Socket wrench
- Phillips Screwdriver