

INSTALLATION INSTRUCTIONS

CP030200077

CP030200198

[2021+ Ford Bronco Sport]

Thank you for purchasing our products! Please contact us for any issues!

Parts List:

- 4 Self Drilling Screws

STEP 1 When you receive this product, we recommend that you should check the accessories before the instruction.

STEP 2 The combination should be set with the **DOOR OPEN** in order to test the lock combination effectively without locking yourself out.

STEP 3 Clear out the contents of the center console for now, including the factory mat at the bottom of the console.

STEP 4 With the door in the open position, carefully slide in the safe body with the lock facing towards the front of the vehicle console. Be sure that the vault is seated all the way down into the console compartment.

STEP 5 Insert the **4 SELF DRILLING SCREWS** by hand, and use a Socket Wrench, complete tightening until the screw heads fully contact the insert nuts and STOP!

STEP 6 Tighten the bolts, **DO NOT OVER TIGHTEN, THIS COULD DAMAGE THE CONSOLE.**

STEP 7 Re-insert the padding that was removed before installation.

STEP 8 Enjoy your purchase!

Tools Needed:

- Impact drill or Socket wrench
- 10mm Socket bit