

INSTALLATION INSTRUCTIONS

CP030200337

[2015-2020 Ford F150, 2017-2022 Ford 250/350/450 Super Duty, 2018-2024 Ford Expedition with Full Floor Console]

Thank you for purchasing our products! Please contact us for any issues!

Accessories List:

- 4 Self-Tapping Screws
- 4 Nuts
- 1 backup key

Tools Needed:

- Open-end Wrench
- Punching cone
- Phillips Screwdriver

Note 1 When you receive this product, we recommend that you should check the accessories before the instruction.

Note 2 The fingerprint code should be set with the **DOOR OPEN** to test the lock effectively without locking yourself out.

Safe installation:

STEP 1 Empty the armrest box including the factory mat at the bottom.

STEP 2 Place the top panel of the safe **into the armrest box through the diagonal of the** armrest box. Then **open the lid and raise the panel to the top of the armrest box.**

STEP 3 Put the brackets into the armrest box through the safe door. Note there are two screws on both sides of the top panel. Confirm the reserved holes of the brackets are attached to the screws of the panel.

STEP 4 Hand **Nuts** on the screws of the panel, then use an Open-end wrench to tighten the nuts. Do not overtighten the nuts, overtightening will damage the screws.

STEP 5 Use the Screwdriver to screw the **Self-tapping Screws** through the reserved holes of the safe into the armrest box. Also do not overtighten the screws.

STEP 6 Enjoy your purchase. Any issues please contact us.