

# INSTALLATION INSTRUCTIONS

CP030200097

**[For 2021+ Ford Mustang Mach-E]**

**Thank you for purchasing our products! Please contact us for any issues!**

## Parts List:

- 4 3/4" Self-Tapping Screws
- 4 Acorn Nuts
- 1 Handle Awl
- 1 Open End Wrench
- 1 Phillips Screwdriver

**STEP 1** When you receive this product, we recommend that you should check the accessories before the instruction.

**STEP 2** The combination should be set with the **DOOR OPEN** in order to test the lock combination effectively without locking yourself out.

**STEP 3** Clear out the contents of the center console for now, including the factory mat at the bottom of the console.

**STEP 4** Place the Top Assembly of the console safe into the console compartment with the nose down towards the front, until it touches the bottom.

**STEP 5** Adjust the top assembly so that you can pull it towards the top, and the contour of the top assembly matches that of the opening of the console compartment.

**STEP 6** Hold the top assembly against the top lip of the console compartment, then place the **2** side brackets so that the bottom lip sits on the bottom lip of the console compartment, and the **2 STUDS** on either side of the top assembly fit through the holes in the side brackets.

**STEP 7** Secure the brackets to the sides of the top assembly using **4 Acorn NUTS** onto each of the studs on the top assembly. **WARNING! OVERTIGHTENING THE NUTS WILL CAUSE DAMAGE TO THE THREADS.**

**STEP 8** Using an impact drill with a Phillips head attachment or a Phillips head screwdriver, secure the two side brackets to the sides of the console compartment using the **4 SELF-TAPPING SCREWS**.

**STEP 9** Tighten the screws, **DO NOT OVER TIGHTEN, THIS COULD DAMAGE THE CONSOLE.**

## Tools Needed:

- Impact drill or Socket wrench