

# INSTALLATION INSTRUCTIONS

CP030200393

[2016- 2022 Honda Ridgeline, Passport, and Pilot]

**Thank you for purchasing our products! Please contact us for any issues!**

## Parts List:

- 2 M6\*30 Bolts
- 1 backup key
- 1 sharp tool

**STEP 1** When you receive this product, we recommend that you should check the accessories before the instruction.

**STEP 2** The combination should be set with the **DOOR OPEN** in order to test the lock combination effectively without locking yourself out.

**STEP 3** Open the door, use the wrench to loosen the nuts under the lid of the safe, there are four nuts, take off the lid from the safe bottom.

**STEP 4** Clear out the contents of your armrest box.

**STEP 5** Put the bottom of the safe into the armrest box, ensure that the safe is seated all the way down into the armrest box. Then put the lid on the bottom, tighten the nuts which are loosened according to step 3.

**STEP 6** Insert the 2 M6\*30 Bolts into the reserved holes of the armrest box bottom . Then using a Socket Wrench, tighten the bolts!

**STEP 7** Tighten the bolts, **DO NOT OVER TIGHTEN, THIS COULD DAMAGE THE CONSOLE.**

**STEP 8** Re-insert the padding that was removed from the safe before installation.

**STEP 9** Enjoy your purchase!

## Tools Needed:

- Socket wrench