

Installation Instructions

CP030200482

[Fits: Lincoln Aviator 2019-2023+]

Thank you for your purchase! Please contact us for any issues!

Hardware List:

4 x Self-Tapping Screws

Tools Needed:

Phillips Screwdriver

Punching cone

Note 1 When you receive this product, we recommend you that you should check the hardware before installation.

Note 2 The fingerprint code should be set with the **DOOR OPEN** to test the lock effectively without locking yourself out.

Safe installation:

STEP 1 Empty the armrest box including the factory mat at the bottom.

STEP 2 Set the safe into the armrest box.

STEP 3 Use the punching cone to poke holes in the wall of the armrest box through the reserved holes of the safes.

STEP 4 Hand the Self-tapping screws into the reserved holes of the safe and use a screwdriver to tighten the screws into the armrest box. **DO NOT OVER-TIGHTEN THESE SCREWS, THIS COULD DAMAGE THE CONSOLE.**

STEP 5 Enjoy your purchase! Any issues please contact us!

