

# INSTALLATION INSTRUCTIONS

CP030200329

[2010-2024 Toyota 4Runner]

**Thank you for purchasing our products! Please contact us for any issues!**

## Accessories list:

- 2 PC Bolts
- 1 PC Backup key

## Tools Needed:

- Socket Wrench

**Note 1** When you receive this product, we recommend that you should check the accessories before the instruction.

**Note 2** The fingerprint should be set with the **DOOR OPEN** to test the lock effectively without locking yourself out.

## Safe installation:

**STEP 1** Empty the armrest box including the factory mat at the bottom.

**STEP 2** Use a wrench to remove the **2 Bolts** at the bottom of the armrest box.

**STEP 3** Open the safe and remove the padding from the bottom of the inside of the safe.

**STEP 4** Set the safe into the armrest box.

a. Keep the safe open and ensure the safe is inserted into the armrest box correctly, make sure that the reserved holes at the bottom of the safe line up with the holes in the armrest box.

**STEP 5** Use a wrench to tighten the bolts, **DO NOT over-tighten bolts, over-tightening will damage the console.**

**STEP 6** Enjoy your purchase. Any issues please contact us.