

INSTALLATION INSTRUCTIONS

CP030200956

CP030200957

CP030200959

[fit 2007~2024 Toyota FJ Land Cruiser]

Thank you for purchasing our products! Please contact us for any issues!

Hardware List:

- 2 Bolts
- 2 Washers



Tools Needed:

- Socket wrench

Note 1 When you receive this product, we recommend that you check the hardware before installation.

Note 2 The password should be set with the **DOOR OPEN** to test the lock effectively without locking yourself out.

Safe installation:

STEP 1 Empty the armrest box including the factory padding at the bottom.

STEP 2 Use the wrench to remove the **2 FACTORY BOLTS** from the bottom of the armrest box.

STEP 3 Place the safe into the armrest box. To ensure that 2 holes in the base of the safe should align with the holes in the armrest box.

STEP 4 Use a wrench to tighten the bolts with the washers. **DO NOT** over-tighten, over-tightening may damage the console.

STEP 5 Place the padding in the floor of the safe.

Enjoy your purchase! Any issues please contact us!