

INSTALLATION INSTRUCTIONS

CP030200343

[2005 to 2015 Toyota Tacoma]

Thank you for purchasing our products! Please contact us for any issues!

Parts List:

- 2 10mm Bolts
- 2 Washers
- 1 PC Backup key
- 1 PC Sharp tool

STEP 1 When you receive this product, we recommend that you should check the accessories before the instruction.

STEP 2 The combination should be set with the **DOOR OPEN** in order to test the lock combination effectively without locking yourself out.

STEP 3 Clear out the contents of the center console for now, including the factory mat at the bottom of the console.

STEP 4 Remove the cover from the underside of the console lid using a Phillips screwdriver to remove the **5 FACTORY SCREWS**. Then remove the lid from the hinge by unscrewing the **4 FACTORY BOLTS** attached to the lid.

STEP 5 Remove the plastic cover on both sides of console lid hinge (this can be removed with your fingernails or a flathead screwdriver) then proceed to remove the hinge by removing the factory screws used to hold it in place.

STEP 6 Remove the **2 BOLTS** at the bottom of the console compartment (use a 10mm socket to remove these bolts)

STEP 7 Remove the padding from the bottom of the inside of the safe.

STEP 8 Set the safe into the center console.

- To ensure the safe is set in the console properly, make sure that the open slots at the Bottom of the safe line up with the factory screw holes from **STEP 6**.

STEP 9 Using your 10mm fastening device, insert the **10MM BOLTS** into the factory holes at the bottom of the safe (these holes should line up with the factory screw holes at the bottom of the compartment)

STEP 10 Tighten the bolts, **DO NOT OVER TIGHTEN, THIS COULD DAMAGE THE CONSOLE.**

STEP 12 Re-apply the hinge to its original location, the plastic covering to each side of the hinge, and then re-apply the lid to the hinge and the lid undercover to the lid.

Tools Needed:

- Impact drill or Socket wrench
- 10mm Socket bit