

INSTALLATION INSTRUCTIONS

CP030200331

[2016-2024 Toyota Tacoma]

Thank you for purchasing our products! Please contact us for any issues!

Parts List:

- 2 PC Bolts
- 1 PC Backup key

Tools Needed:

- Socket Wrench

Note 1 When you receive this product, we recommend that you should check the accessories before the instruction.

Note 2 The fingerprint should be set with the **DOOR OPEN** test the lock effectively without locking yourself out.

Safe installation:

STEP 1 Empty the armrest box including the factory mat at the bottom.

STEP 2 Use a socket wrench to remove the **2 BOLTS** at the bottom of the armrest box.

STEP 3 Remove the padding from the bottom of the inside of the safe.

STEP 4 Set the safe into the armrest box.

a. Keep the safe open and ensure the safe is inserted into the armrest box correctly, make sure that the reserved holes at the bottom of the safe line up with the holes in the armrest box.

STEP 5 Use a socket wrench to tighten the bolts, **DO NOT over-tighten bolts, over-tightening will damage the armrest box.**

STEP 6 Enjoy your purchase. Any issues please contact us.