

INSTALLATION INSTRUCTIONS

CP030200078

CP030200100

CP030200101

[2014-2021 Toyota Tundra]

Thank you for purchasing our products! Please contact us for any issues!

Parts List:

- 1 Short 8mm bolt with 10mm head.
- 1 Long 8mm bolt with 10mm head
- 2 Washers

STEP 1 When you receive this product, we recommend that you should check the accessories before the instruction.

STEP 2 The combination should be set with the **DOOR OPEN** in order to test the lock combination effectively without locking yourself out.

STEP 3 Clear out the contents of the center console for now, including the factory mat at the bottom of the console.

STEP 4 Use a 10mm fastening device to remove the **RIGHT FRONT** and the **LEFT REAR** bolts from the bottom of the console compartment.

STEP 5 Remove the padding from the bottom of the inside of the safe.

STEP 6 Set the safe into the center console.

- a. To ensure that the safe is properly inserted into the console, make sure that the factory slots in the safe line up with the factory screw holes from the bolts that were removed in **STEP 3**.

STEP 7 Using your 10mm fastening device, insert the **SHORTER 10MM BOLT** along with **1 WASHER** in the **FRONT RIGHT** screw hole, and the **LONGER 10MM BOLT** with **1 WASHER** in the left rear screw hole.

- a. When placing the bolts into their respective slots, make sure that the **WASHER** is placed between the bolt and the safe.

STEP 8 Tighten the bolts, **DO NOT OVER TIGHTEN, THIS COULD DAMAGE THE CONSOLE.**

Tools Needed:

- Impact drill or Socket wrench
- 10mm Socket bit