



HydraBarrier[®] Repair Instructions

This is a guide that describes how to repair any of our Watershed Innovations' HydraBarrier[®] products that may have suffered a small puncture.

Materials Required

The following materials are required in order to repair a HydraBarrier:

1. A HydraBarrier vinyl patch.
2. Waterproof vinyl adhesive.
 - This can be readily purchased from a local hardware store
 - Safety Note: Be sure to follow any safety guidelines outlined by the manufacturer of the vinyl adhesive.
3. Eye protection.
4. Cloth to clean the punctured area and patch material



HydraBarrier Preparation

In order to patch a HydraBarrier please use the following steps:

1. Empty the HydraBarrier with the puncture.
 - Note: It may be possible to patch a HydraBarrier when full of water. Consult vinyl adhesive instructions to see if it can support this.
2. Clean the effected area on the HydraBarrier.
3. Clean the patch provided with the HydraBarrier.



HydraBarrier Repair Instructions

1. Ensure that you are wearing eye protection and following any other guidelines required by the vinyl adhesive manufacturer.
2. Per the adhesive manufacturer's recommendations apply the adhesive to the patch and punctured area.
3. Apply the patch.
4. Wait until glue has set per glue manufacture's instructions.
5. Now you can refill and reuse your HydraBarrier.



Trademarks and/or registered trademarks of Watershed Innovations, LLC.. Information is subject to change without notice. Copyright 2014 Watershed Innovations. All rights reserved.

Watershed Innovations Repair Instructions, rev .2, 2-23-14