

Wallpaper Install Instructions

Prep: The KEY to a GREAT result

- Peel and Stick is for Latex or Primed, Flat, Clean Surfaces ONLY; otherwise, use traditional pasted wallpaper
- Lay paper flat for 90 min.
- Place test piece on wall to gauge adhesion
- If oil/wax present, then clean walls with Sher-Will-Clean by Sherwin Williams - FOLLOW all safety instructions
- Final Clean Walls with an Isopropyl Alcohol Soaked Rag

Install: Go Slow, Stay Hydrated

- Measure 24.5" from left edge of the project area; draw a straight vertical line 24.5" from the left edge of the project area using a straight edge from top of the wall to the bottom
- Use this vertical line to line up the first panel of wallpaper
- Peel back 6" of the wallpaper backing from the top; starting at the top, place wallpaper on the wall, removing 6" at a time as you work down, smoothing the paper with an installation tool
- Place your next piece on the wall, overlapping the first piece by 0.5" and line up the design repeat, working from the top 6" at a time, as you did before.
- Finish placing all panels with the overlap, trim the tops, bottoms, and right edge a utility knife
- Make an extra pass with the tool over all edges and seams.
- Apply DreamScape DreamGuard over wallpaper for high traffic/high abrasion areas for a very durable finish.