Wallpaper Install Instructions

Traditional Wallpaper

- We recommend professional installation trust them over these instructions.
- Prepare walls by filling holes, leveling rough areas, and cleaning surfaces
- Use a laser level (or the like) to get straight starting lines

Install: Go Slow, Stay Hydrated

- Lay paper face-down on a flat surface
- Apply pre-mixed paste to the surface start in the center and spread toward edges
- "Book" the wallpaper lightly folding the adhesive covered paper over itself (top meeting the bottom) to meet at the center - do not crease the paper! Let sit for 20-30 minutes, or as specified on the paste instructions
- Start with the left edge of the area, hang wallpaper on level line, with a few extra inches at the top. Smooth paper gently with hands and provided felt-edged tool
- Continue working top down, butting the edge of the panel with the edge of previous panel.
- Wipe away excess paste with sponge and clean water
- Trim the top and bottom with a utility knife
- Apply <u>DreamGuard</u> over wallpaper for high traffic/high abrasion areas for a very durable finish.

