

WAGON BIN INSTRUCTIONS

ASSEMBLING WAGON BIN

(BIN WILL COME INSTALLED ON LID IN DOWN POSITION)

- 1 Locate Velcro straps on top end (same end as handle straps) and release from AnchR pins
- 2 Pivot top end up until vertical on opposite end
- Unfold and extend base back to opposite AnchR pins
- 4 Loop base velcro straps under and around AnchR pins and secure back on corner base of bin
- **5** Ensure all straps are safely secured around pins on all 4 corners
- Remove logo plate
- 7 Place tow plate on side of cooler and ensure 4 holes align with tread points on cooler
- Secure tow plate using same hex bolts from logo plate using hex wrench and ensure secure and free from any rattling
- When towing the RollR, insert safety pin snuggly into smaller hole and through tow hitch as shown. Store the safety pin in the same location on BikR plate when not in use

COLLAPSING WAGON BIN

- 1 Pull base panel up from base until flush with vertical wall using provided finger loop
- 2 Remove Velcro straps from AnchR pins on end with no top Velcro straps
- 3 Use provided finder loop located in center of base material and pull up to collapse bin and ensure base material cleanly inside folded bin
- 4 Rotate folded bin back down into recess of cooler lid
- 5 Secure top Velcro straps under and around AnchR pins and secure back on top corners of bin
- **6** Ensure all straps are safely secured around pins on all 4 corners

REMOVING WAGON BIN

- 1 Remove Velcro straps from all 4 corners of RollR Bin and remove from lid
- **2** Follow steps above to assemble or collapse



WAGON BIN INSTRUCTIONS

DIAGRAM

