



Noisekillers Limited,
Unit 29 Airfield Approach Business Park,
Flookburgh,
Cumbria,
LA11 7NG
Tel 01524 963 680

Vehicle Model:

Cherokee (2002-Onwards)	Page 2
Cherokee (Upto-2002)	Page 3
Grand Cherokee (2001-Onwards)	Page 4
Patriot	Page 5
Wrangler (1997-2006)	Page 6
Grand Cherokee (Upto-2001)	Page 7

JEEP CHEROKEE (2002-Onwards)

Contents of full kit 14 items and 12 pads

Items marked with an * are self-adhesive and should be applied to a clean and dry surface only. We recommend the use of a small roller to apply even pressure.

ENGINE BAY

- | | |
|---------|--|
| 1 – 5 * | Adhere these items to the bonnet lid by their shape |
| 6 | Adheres to the top of the bulkhead in the centre |
| 7 | Adheres to the passenger side bulkhead behind the manufacturers cover. |

INTERIOR OF CAB

- | | |
|---------|---|
| 8 | This item fits under the carpet in the driver's side foot well |
| 9 | This item fits along the side of the transmission tunnel driver's side. |
| 10 | This item fits under the carpet in the passenger side foot well |
| 11 | This item fits along the side of the transmission tunnel passenger side |
| 12 & 13 | These items fit under the rear foot well carpets |
| Pads | Fit two pads to the area under the rear seat under the toolbox |

LOAD SPACE

- | | |
|------|---|
| 14 | This item fits under the rear load space carpet |
| Pads | Fit three pads to each rear wheel arch. |

- | | |
|-------|--|
| DOORS | Fit one pad to the outer skin of each door |
|-------|--|

THE FITTING IS NOW COMPLETE

Happy Motoring

JEEP CHEROKEE (Upto-2001)

Contents of full kit 13 items and 4 pads

Items marked with an * are self-adhesive and should be applied to a clean and dry surface only.
We recommend the use of a small roller to apply even pressure.

ENGINE BAY

1 – 3 * Adhere these items to the bonnet lid by their shape

A piece of barrier mat for the enthusiast who wishes to cover the bulkhead.

INTERIOR OF CAB

- | | |
|-------|---|
| 4 | This item fits under the carpet in the driver's side foot well |
| 5 | This item fits along the side of the transmission tunnel driver's side. |
| 6 | This item fits under the carpet in the passenger side foot well |
| 7 | This item fits along the side of the transmission tunnel passenger side |
| 8 & 9 | These items fit under the rear foot well carpets |
| 10 | This item fits under the rear seats |

LOAD SPACE

- | | |
|-----------|---|
| 11* & 12* | These items adhere to the rear wheel arches |
| 13 | This item fits on the load space floor |

DOORS Fit one pad to the outer skin of each door

THE FITTING IS NOW COMPLETE

Happy Motoring

JEEP GRAND CHEROKEE (2001-Onwards)

Contents of the full kit 14 Items and 8 pads

Items marked with an * are self-adhesive. We recommend the use of a small roller to apply even pressure.

UNDERBONNET

1 – 4* These adhere to the bonnet lid by their shape

INTERIOR CAB

- 5 Undo the carpet kick strip by the foot well and slide this pad under the driver's side carpet.
- 6 This pad fits along the side of the transmission tunnel
- 7 This pad fits under the passenger side front carpet
- 8 This pad fits along the side of the passenger side transmission tunnel
- 9 & 10 These pads fit under the rear foot well carpets

LOAD SPACE AREA

- 11 & 12* Adhere the items onto the rear wheel arches
- 13* Adhere this piece to the base of the spare wheel well
- 14 This pad fits under the rear load space carpet

PADS

Adhere two pads to the outer skin of each door

**The Fitting is now Complete
Happy Motoring**

JEEP Patriot - 2009

Contents of full kit 22 items and 4 pads

Items marked with an * are self-adhesive and should be applied to a clean and dry surface only. We recommend the use of a small roller to apply even pressure.

ENGINE BAY

1 – 4* Adhere these items to the bonnet lid by their shape

INTERIOR OF CAB

Loosen the trim from the transmission tunnel to fit items 5 to 8

- 5 This item fits under the carpet in the driver's side foot well
- 6 This item fits on the side of the transmission tunnel drivers side
- 7 This item fits under the passenger side front carpet
- 8 This item fits along the side of the transmission tunnel passenger side. Undo the bolts holding the rear seat frame and slide pads under rear footwell carpet
- 9 & 10 These fit under the rear carpets
- 11 This item fits under the rear seat

LOAD SPACE

- 12* This piece adheres to the boot floor top left
- 13* This piece adheres to the middle top of the boot floor
- 14* This piece adheres to the top right of the boot floor
- 15* This piece adheres to the lower left side of the boot floor
- 16* This piece adheres to the lower right side of the boot floor
- 17-20* These pieces adhere to the side walls of the spare wheel well
- 21* This piece adheres to the base of the spare wheel well
- 22 This piece fits on top of the spare wheel and under the boot carpet

DOORS

Fit one pad to the outer skin of each door only if your are experienced at removing the door card. Seek advice from your dealer as to how the door card is constructed

THE FITTING IS NOW COMPLETE, Happy Motoring.

JEEP WRANGLER

(1997 – 2006)

Contents of the full kit 17 items and 17 pads

Items marked with an * are self-adhesive and should be applied to a clean and dry surface only we recommend the use of a small roller to apply even pressure.

Engine Bay

- 1 & 2* Fit these items to the bonnet lid
- 3 & 4* These items fit to the bulkhead at the back of the engine item No 3 to the drivers side centre bulkhead 4 to the passenger side centre
- Pads Fit three pads around the driver's side-wheel arch and suspension tower. Fit one pad to the passenger side-wheel arch. Fit one pad to the outer wing driver's side and one pad to the passenger side outer wing behind the battery.

Interior Cab section

- 5 & 6* Fit these items to the sidewalls of the foot well on the outer skin of the body. 5 to the driver's side.
- Pads Fit one pad on the floor area under the carpet
- Fit three pads around the bell housing at the top of the transmission tunnel
- 7 & 8 Place pad No 7 under the front floor carpet driver's side 8 under the passenger side
- 9 & 10 Fit these items to the side walls of the transmission tunnel 9 to the drivers side
- Pads Fit one pad in the rear footwells
- Fit one pad onto the rear wall bulkhead in each foot well
- 11 & 12 These items fit under the rear foot well carpet

Rear Section

- 13* Adhere item 13 to the metal covering in the boot floor.
- 14 & 15* Fit these items to the rear wheel arch rear section 14 to the drivers side
- 16 & 17* Fit these items to the front section of the rear wheel arches 16 to the drivers side

Doors

Loosen the door trim and fit one pad to the outer skin of each door

YOUR FITTING IS NOW COMPLETE

JEEP GRAND CHEROKEE

(Upto-2001)

Contents of the full kit 14 Items and 8 pads

Items marked with an * are self-adhesive. We recommend the use of a small roller to apply even pressure.

UNDERBONNET

1 – 4* These adhere to the bonnet lid by their shape

INTERIOR CAB

- 5 Undo the carpet kick strip by the foot well and slide this pad under the driver's side carpet.
- 6 This pad fits along the side of the transmission tunnel
- 7 This pad fits under the passenger side front carpet
- 8 This pad fits along the side of the passenger side transmission tunnel
- 9 & 10 These pads fit under the rear foot well carpets

LOAD SPACE AREA

- 11 & 12* Adhere the items onto the rear wheel arches
- 13* Adhere this piece to the base of the spare wheel well
- 14 This pad fits under the rear load space carpet

PADS

Adhere two pads to the outer skin of each door

The Fitting is now Complete
Happy Motoring