

Vehicle Model:

Caren	Page 2
Mentor	Page 3
Sedona (2000-2005)	Page 4
Shumu	Page 5
Sorrento	Page 6
Sportage	Page 7
Ceed (2006-2012)	Page 8
Ceed (2012-2018)	Page 9
Pro Ceed Estate (2018-Onwards)	Page 10
Rio (2011-2016)	Page 11
Rio (2016-Onwards)	Page 12
Sorrento (2010-Onwards)	Page 13
Sportage (2004-2010)	Page 14
Sportage (2010-Onwards)	Page 15
XCeed (2018-Onwards)	Page 16



Noisekillers Limited,
Unit 29 Airfield Approach Business Park,
Flookburgh,
Cumbria,
LA11 7NG
Tel 01524 963 680

KIA CAREN

Contents of the full kit 15 items and 10 pads

Items marked with an * are self-adhesive and should be applied to a clean and dry surface only.
We recommend the use of a small roller to apply even pressure.

ENGINE COMPARTMENT

1-8* These items adhere to the bonnet lid by their shape,

INTERIOR OF VEHICLE

- 9 This item is fitted under the carpets on the driver side of the vehicle
- 10 As 9 but on the passenger side
- 11 & 12 These fit under the rear footwell carpets
- 13 This pad fits under the Rear Seat
- 14* This adheres to the base of the spare wheel
- 15 This fits under the boot carpet

PADS

Ease off the plastic covering on the rear wheel arches and adhere 3 pads to each wheel arch

DOOR PADS

Fit one pad to the outer skin of each door Do not fit the door pads unless you are competent at removing the door card. Your dealer should be able to fit these at your next service.

The Fitting is now Complete
Happy Motoring

KIA MENTOR

Contents of the kit 19 Items and 4 pads

Items marked with an * are self-adhesive and should be applied to a clean and dry surface only. We recommend the use of a small roller to apply even pressure

ENGINE COMPARTMENT

- 1-8* These items adhere to the bonnet lid
- 9* This item adheres to the centre bulkhead
- 10* This item adheres to the passenger side bulkhead

INTERIOR OF VEHICLE

- 11&12 Undo the carpet kick strips by the door and slide these pads under the carpet 11 to the driver's side
- 13&14 These pads fit under the carpet in the rear footwells
- 15 This pad fits under the rear seat

BOOT COMPARTMENT

- 16&17* These adhere to the rear wheel arches after you remove the cover 16 to the passenger side
- 18* This pad adheres under the spare wheel
- 19 This pad fits above the spare wheel and under the boot carpet

DOOR PADS

Fit one pad onto the outer skin of each door

The Fitting is now Complete
Happy Motoring

KIA SEDONA 2000 - 2005

Contents of the full kit 17 items and 10 pads

Items marked with an * are self-adhesive and should be applied to a clean and dry surface only.
We recommend the use of a small roller to apply even pressure.

ENGINE COMPARTMENT

1-10* These items adhere to the bonnet lid by their shape, in the case of the diesel version it will be necessary to trim round the air intake on the bonnet.

***** Under no circumstances must the air intake air-flow be reduced, as this may invalidate the vehicle warranty.**

INTERIOR OF VEHICLE

Items 11 & 12 are fitted under the front carpets

- 11 This item is fitted under the carpets on the driver side of the vehicle
- 12 As 11 but on the passenger side

All other interior parts are fitted on top of the cab carpet and under the Kia drop in floor carpets

- 13 This is fitted in between the two front seats
- 14 This fits behind the front seats
- 15 This fits in front of the second row of seats
- 16 This fits in front of the third row of seats
- 17 This fits in the Load Space area

PADS

Ease off the plastic covering on the rear wheel arches and adhere 3 pads to each wheel arch

DOOR PADS

Fit one pad to the outer skin of each door. Do not fit the door pads unless you are competent at removing the door card. Your dealer should be able to fit these at your next service.

The Fitting is now Complete
Happy Motoring

KIA SHUMU 2000

Contents of the kit 21 Items and 10 pads

Items marked with an * are self-adhesive and should be applied to a clean and dry surface only. We recommend the use of a small roller to apply even pressure

ENGINE COMPARTMENT

- 1-8* Remove the manufacturers under bonnet, if fitted, cover and fit these items to the skin of the bonnet lid. Location is determined by their shape. Re-fit manufacturers cover.
- 9* This item adheres at the base of the water bottle
- 10* This item adheres to the bulkhead near the brake servo
- 11* This item adheres to the centre bulkhead to the left of the wiper motor
- 12* This item adheres to the bulkhead
- 13* This item adheres under the power steering fluid filler

INTERIOR OF VEHICLE

- 14 Fit this item under the carpets in the front passenger footwell (lift trim at the bottom of the doors and slide the acoustic material under the carpet)
- 15 As with 14 on the driver's side
- 16 Rear footwell passenger side
- 17 Rear footwell driver's side
- 18&19 Fit one pad under each of the rear seats

BOOT COMPARTMENT

- 20 Fit this item under the spare wheel
- Fit 6 anti vibration pads to the side wall of the spare wheel storage Compartment, evenly spaced. Replace spare wheel etc
- 21 Fit this item under boot carpet. Re-fit boot carpet
- Remove the door panels and fit one anti vibration pad to the outer skin of each door ensuring that the metal is clean to help adhesive to bond

The Fitting is now Complete
Happy Motoring

KIA SORENTO

Contents of the full kit 19 items and 10 pads

Items marked with an * are self-adhesive and should be applied to a clean and dry surface only.
We recommend the use of a small roller to apply even pressure.

ENGINE COMPARTMENT

1-10* These items adhere to the bonnet lid by their shape.

INTERIOR OF VEHICLE

- 11 This piece fits underneath the driver's side front carpet
- 12 This piece fits along the side of the transmission tunnel on the driver's side
- 13 This piece fits along the side of the transmission tunnel of the passenger side
- 14 This piece fits underneath the passenger's side front carpet
- 15 & 16 These pieces fit under the rear foot well floor carpet
- 17 This piece fits under the rear seat

BOOT COMPARTMENT

- 18* This piece adheres to the floor in the rear load space under the tray
- 19 This piece fits on top of piece number 18
- PADS Ease of the plastic covering on the rear wheel arches and slide 3 pads to each wheel arch

DOOR PADS

Fit one pad to the outer skin of each door

The Fitting is now Complete
Happy Motoring

KIA SPORTAGE 1993 to 2004

Contents of the full kit 13 items and 4 pads

Items marked with an * are self-adhesive and should be applied to a clean and dry surface only.
We recommend the use of a small roller to apply even pressure.

ENGINE COMPARTMENT

1-4* These items adhere to the bonnet lid by their shape,

INTERIOR OF VEHICLE

- | | |
|----------|---|
| 5 & 6 | Item 5 fits to the drivers side front floor and 6 to the side of the transmission tunnel underneath the floor carpets |
| 7 & 8 | Item 7 to the passenger side front floor and 8 to the passenger transmission |
| 9 & 10 | These fit under the rear footwell carpets |
| 11 & 12* | These adhere to the rear wheel arches |
| 13 | This piece fits under the rear load space carpet |

DOOR PADS

Fit one pad to the outer skin of each door Do not fit the door pads unless you are competent at removing the door card. Your dealer should be able to fit these at your next service.

The Fitting is now Complete
Happy Motoring

KIA CEED saloon and estate 2006 to 2012

Contents of the full kit 23 items and 4 pads

Items marked with an * are self-adhesive and should be applied to a clean and dry surface only.
We recommend the use of a small roller to apply even pressure.

ENGINE COMPARTMENT

1-10* These items adhere to the bonnet lid by their shape,

INTERIOR OF VEHICLE

11 & 12 These items fit under the front carpets 11 driver side
13 This fits along the side of the transmission tunnel passenger side
14 & 15 These fit under the rear footwell carpet
16 This piece fits under the rear seat

BOOT COMPARTMENT

17* This piece adheres to the drivers side rear wheel arch
18* This adhere to the passenger side wheel arch
19* This adheres to the base of the spare wheel
21 -22* These adhere to the side walls of the spare wheel
23 This piece fits under the boot carpet

Door Pads

Four pads are include free of charge with the kit for fitting to the outer skin of the door. Do not attempt to fit these unless you are competent at removing door cards – seek advice from your dealer to ensure you don't disconnect any electrical wires

The Fitting is now Complete
Happy Motoring



Noisekillers Limited,
Unit 29 Airfield Approach Business Park,
Flookburgh,
Cumbria,
LA11 7NG
Tel 01524 963 680

KIA CEED saloon and estate 2012 - 2018

Contents of the full kit 18 items and 4 pads

Items marked with an * are self-adhesive and should be applied to a clean and dry surface only.
We recommend the use of a small roller to apply even pressure.

ENGINE COMPARTMENT

1-4* These items adhere to the bonnet lid by their shape

INTERIOR OF VEHICLE

5 & 6 These items fit under the front 5 to driver's side
7 & 8 These fit along the side of the transmission tunnel
9 & 10 These fit under the rear footwell carpet
11 This piece fits under the rear seat

BOOT COMPARTMENT

12* This piece adheres to the driver's side rear wheel arch
13* This adhere to the passenger side wheel arch
14 - 16* These adhere to the side walls of the spare wheel
17* This adheres to the base of the spare wheel
18 This piece fits under the boot carpet

Door Pads

Four pads are include free of charge with the kit for fitting to the outer skin of the door. Do not attempt to fit these unless you are competent at removing door cards – seek advice from your dealer to ensure you don't disconnect any electrical wires

The Fitting is now Complete
Happy Motoring

KIA PRO CEED (ESTATE) 2018 ONWARDS (MK 3)

Contents of the full kit; 21 items and 29 pads

Items marked with an * are self-adhesive and should be applied to a clean and dry surface only. We recommend the use of a small roller to apply even pressure.

ENGINE COMPARTMENT

1-8* Adhere to the bonnet lid by their shape behind your black cover.

INTERIOR OF VEHICLE

- 9 Fits under the driver's side front footwell carpet.
- 10 Fits under the passenger side front footwell carpet.
- 11&12 Fit along the side of the transmission tunnel behind carpet/trim. Item 7 to the driver's side. Fit these at same time as front footwells while carpet is loosened.
- 13&14 These fit under the rear footwell carpet. Pull seat from the front to unclip and gain access.
- 15 Sits under rear seat.
- PADS Adhere 5 pads along the bare metal area of the rear seat upright (where you would kick your heels). Also adhere 1 pad to the top of the centre transmission tunnel.

BOOT COMPARTMENT

- 16-19* Adhere to the side walls of the spare wheel well.
- 20* Adheres to the base of the spare wheel well.
- PADS Adhere 3 pads to the rear wall of the spare wheel well.
Adhere 16 pads to the rear wheel arches, wings and boot floor after removing/loosening the covers/trim. Use 8 pads for each side.
- 21 Fits under the boot carpet.

DOORS

Remove door cards and fit one pad to the outer skin of each door. These are included free of charge and we would only recommend fitting these if you are competent at removing door cards. If we are installing the kit for you these door pads WILL NOT be fitted. Please refer to our FAQs on our website.

The fitting is now complete, **HAPPY MOTORING!**

KIA RIO 2011-2016 (MK 3)

Contents of the full kit; 19 items & 9 pads

Items marked with an * are self-adhesive and should be applied to a clean and dry surface only.
We recommend the use of a small roller to apply even pressure.

ENGINE COMPARTMENT

1-4* Adhere to the bonnet lid by their shape.

INTERIOR OF VEHICLE

- 5 Fits under the driver's side front floor carpet.
- 6 Fits along the side of the transmission tunnel behind the carpet on the driver's side.
- 7 Fits under the passenger side front floor carpet.
- 8 Fits along the side of the transmission tunnel behind the carpet on the passenger side.
- 9&10 Fit under the rear footwell carpet.
- 11 Fits under the rear seat.

REAR BOOT AREA

- 12* Adheres to the driver's side wheel arch.
- PADS Adhere 3 pads to driver's side wing.
- 13* Adheres to the passenger wheel arch.
- PADS Adhere 2 pads to the passenger side wing.
- 14-16* Adhere to the side walls of the spare wheel well.
- 17* Adhere to the base of the spare wheel well.
- 18* Adhere to the boot floor to the right of spare wheel well.
- 19 Fits under the rear load space carpet.

DOORS

Remove door cards and fit one pad to the outer skin of each door. These are included free of charge and we would only recommend fitting these if you are competent at removing door cards. If we are installing the kit for you these door pads WILL NOT be fitted. Please refer to our FAQs on our website.

The fitting is now complete,
HAPPY MOTORING!

KIA RIO

2016 Onwards (MK 4)

Contents of the full kit; 20 items & 21 pads

Items marked with an * are self-adhesive and should be applied to a clean and dry surface only.
We recommend the use of a small roller to apply even pressure.

ENGINE COMPARTMENT

1-4* Adhere to the bonnet lid by their shape.

INTERIOR OF VEHICLE

- 5 Fits under the driver's side front footwell carpet.
- 6 Fits along the side of the transmission tunnel behind carpet on the driver's side.
- 7 Fits under the passenger side front footwell carpet.
- 8 Fits along the side of the transmission tunnel behind carpet on the passenger side.
- 9&10 Fit under the rear footwell carpet.
- 11&12 Fit under the front seats. To get under the carpet you will need to remove seats to gain access otherwise they can sit on top of the carpet.
- 13 Fits under the rear seat.

BOOT COMPARTMENT

- PADS 12 pads are included to fit on the rear wheel arches and wings.
- 14-18* Adhere to the side walls of the spare wheel well.
- 19* Adheres to the base of the spare wheel well.
- PADS 5 pads adhere on the boot floor either side of the spare wheel.
- 20 Fits under the rear load space carpet.

DOORS

Remove door cards and fit one pad to the outer skin of each door. These are included free of charge and we would only recommend fitting these if you are competent at removing door cards. If we are installing the kit for you these door pads WILL NOT be fitted. Please refer to our FAQs on our website.

The fitting is now complete,
HAPPY MOTORING!

KIA SORENTO 2010 onwards

Fitting Instructions

Contents of the full kit 11 items and 10 pads

Items marked with an * are self-adhesive and should be applied to a clean and dry surface only.
We recommend the use of a small roller to apply even pressure.

ENGINE COMPARTMENT

1-6* These items adhere to the bonnet lid by their shape.

INTERIOR OF VEHICLE

7	This piece fits on top of the driver's side front carpet and under the	drop in
carpet		
8	This piece fits underneath the passenger's side front carpet	
9 & 10	These pieces fit under the rear foot well floor carpet	

BOOT COMPARTMENT

Remove the rear seats

11 This piece fits under the carpet in the load space and under the rear seat

Pads Remove or lift the rear wheel arch covers and fit 3 pads to each wheel arch

DOOR PADS

Fit one pad to the outer skin of each door only do this if you are competent at removing door cards. Seek advice from your dealer to ensure you do not disconnect a wire from the electric window mechanism

The Fitting is now Complete
Happy Motoring

KIA SPORTAGE 2004 to 2010

Contents of the full kit 19 items and 4 pads

Items marked with an * are self-adhesive and should be applied to a clean and dry surface only.
We recommend the use of a small roller to apply even pressure.

ENGINE COMPARTMENT

1-7* These items adhere to the bonnet lid by their shape,

INTERIOR OF VEHICLE

8 Item 8 fits to the drivers side front floor under the floor carpet
9 Item 9 to the passenger side front floor under the carpet
10 & 11 These fit under the rear footwell carpets
12 & 13 These fit under the rear seat

LOAD SPACE

14* This piece adheres to the base of the spare wheel
15 -18* These adhere to the side walls of the spare wheel
19 This piece fits under the rear load space carpet

DOOR PADS

Fit one pad to the outer skin of each door Do not fit the door pads unless you are competent at removing the door card. Your dealer should be able to fit these at your next service.

The Fitting is now Complete
Happy Motoring

KIA SPORTAGE 2010 onwards

Contents of the full kit 19 items and 8 pads

Items marked with an * are self-adhesive and should be applied to a clean and dry surface only.
We recommend the use of a small roller to apply even pressure.

ENGINE COMPARTMENT

1-4* These items adhere to the bonnet lid by their shape,

INTERIOR OF VEHICLE

5 This item fits to the driver's side front floor above the carpet but below the drop in floor carpet
6 Item 6 fits under the passenger side front floor carpet
7 & 8 These fit under the rear footwell carpets
9 & 10 These fit under the rear carpet forward of the cross member and under the front seat
11 This fit under the rear seat
Pads Fit two pads each side onto the upright of the seat frame

LOAD SPACE

12 - 15* These adhere to the side walls of the spare wheel
16* This piece adheres to the base of the spare wheel
17* No 17 adheres to the driver's side rear wheel arch
18* No 18 adheres to the passenger side rear wheel arch
19 This piece fits under the rear load space carpet

DOOR PADS

Fit one pad to the outer skin of each door Do not fit the door pads unless you are competent at removing the door card. Your dealer should be able to fit these at your next service.

The Fitting is now Complete
Happy Motoring

KIA XCEED 2018 Onwards

Contents of the full kit; 24 items and 11 pads

Items marked with an * are self-adhesive and should be applied to a clean and dry surface only.

We recommend the use of a small roller to apply even pressure.

ENGINE COMPARTMENT

1-8* These items adhere to the bonnet lid by their shape.

INTERIOR OF VEHICLE

9 Fits under the driver's side front footwell carpet. You will need to remove plastic trim by the door sill and bonnet catch to be able to pull the carpet away and slide the piece in.

10 Fits under the passenger side front carpet in the same way as the driver's side.

11&12 These fit along the side of the transmission tunnel behind the carpet/trim. You may find this easier to fit by removing plastic trim at the side of the tunnel. On the driver's side you will also need to remove the footrest. Remove the rubber circles on the footrest to reveal the screws.

13&14 These fit under the rear footwell carpet. To gain access pull the rear seat sharply upwards to be able to pull carpet back.

PADS Cover the bare metal upright between the footwells and rear seat with 7 pads.

15 This piece fits under the rear seat. Clip rear seat back in.

BOOT COMPARTMENT

16&17* These adhere to the rear wheel arches after loosening the trim.

18-21* These adhere round the side walls of the spare wheel well.

22* Adheres to the back wall of the spare wheel well.

23* This adheres to the base of the spare wheel well.

24 Fits above spare wheel well and under the boot carpet.

DOORS

Remove door cards and fit one pad to the outer skin of each door. These are included free of charge and we would only recommend fitting these if you are competent at removing door cards. If we are installing the kit for you these door pads WILL NOT be fitted. Please refer to our FAQs on our website.

The fitting is now complete, **HAPPY MOTORING!**