

Exterior Oil Treatment

A professional finish prolongs the durability of exterior wood considerably as well as protecting the wood from outdoor influences, such as sunlight, rain, humidity and fluctuating temperatures.

Products Needed

WOCA Exterior Oil

WOCA Exterior Cleaner

WOCA Exterior Gel

Padco Roller



Buy Now!

Buy Now!

Buy Now!

Buy Now!

Instructions

1. Clean new wooden surfaces as well as old surfaces with WOCA Exterior Cleaner before starting the oil treatment.
2. Then leave the wood to dry for at least 24 hours so that the humidity is not above 17%. Sand down any rough wood fibers with 120 grit sandpaper.
3. Apply in dry weather only with min. temp. 13°C (55°F). Avoid direct sunlight and high temperatures.
4. Stir the oil thoroughly before and during use.
5. Apply an even and thin coat of oil with a brush. Treat the end grain wood first. The wet oil may have a white shade. When the water has evaporated after a few minutes, the wood will appear oiled.
6. Wipe off any excess oil with clean cotton cloths after no more than 5 minutes. Take particular care of removing excess oil from joints and grooves.
7. If the surface does not appear saturated with oil, repeat steps 5 and 6.
8. When the wood is dry, it may be polished with a polishing pad or polishing machine to ensure an extra hard-wearing surface.

9. It takes 24 to 48 hours for the oil to harden thoroughly, depending on weather conditions and outdoor temperature. The wood must not be exposed to water during this period.
10. Attention (for furniture): Please note that Exterior Oil in the black, anthracite and walnut color are recommended to be finished with a coat of Exterior Oil Natural to avoid excess color coming off.

Repeat the oil treatment when required. Start cleaning the surface with WOCA Exterior Cleaner. Then follow the steps under basic treatment.