

## FOUNDATIONLESS REQUIREMENTS:

- Centered on a square foot area that is free from cracks, seams, and walls.
- Reinforced Concrete with Pressure of 3000 psi and Soil Pressure of 2500 psf.
- Chemical anchor bolts to withstand a minimum of 2,850 lbs. of pull out force.
- Concrete must contain wire mesh reinforcement.

## 1) JIB CRANE FOUNDATION REQUIREMENTS ARE BASED ON A SOIL PRESSURE OF 2500 LBS PER SQUARE FOOT. CONCRETE RECOMMENDED FOR JIB CRANE FOUNDATION IS 3000 LBS PER SQUARE INCH OF COMPRESSIVE FORCE.

2) DO NOT SCALE FROM THIS DRAWING.

150 LB CAPACITY



600 FISHERS RUN P.O. BOX 593 FISHERS, NY 14453-0593

MODEL NO: WSJ360-NP6-150-10-16

CAPACITY: 150 LBS SPAN: 16 FT H.U.B.: 10 FT

QUANTITY: 1

SHIPPING WT.: 717 LBS

DRAWN: DATE: 4/13/2016
C.O.#: Sdarby00004 P/N: Sdarby00004.1A