



USE 3/4" ANCHOR BOLTS
ANCHOR BOLTS MUST BE EMBEDDED AT LEAST 4" INTO FLOOR.
HAVE A MINIMUM OF TWO THREADS ABOVE NUT
MAKE SURE COLUMN WELDMENTS ARE PLUMB
ATTACH RUNWAYS TO COLUMN HEADERS USING 1/2-13 1.5" LG. BOLTS
LEVEL RUNWAYS AND MAKE SURE THAT THEY ARE PARALLEL WITHIN t.125"





