

FOUNDATIONLESS REQUIREMENTS:

- Centered on a square foot area that is free from cracks, seams, and walls.
- Reinforced Concrete with Pressure of 3000 psi and Soil Pressure of 2500 psf.
- Chemical anchor bolts to withstand a minimum of 3,470 lbs. of pull out force.
- Concrete must contain wire mesh reinforcement.

NOTES:

JIB CRANE FOUNDATION REQUIREMENTS ARE BASED ON A SOIL PRESSURE OF 2500 LBS PER SQUARE FOOT. CONCRETE RECOMMENDED FOR JIB CRANE FOUNDATION IS 3000 LBS PER SQUARE INCH OF COMPRESSIVE FORCE.

150 LB CAPACITY

CREATED BY: WISCOLIFT INC

600 FISHERS RUN

P.O. BOX 593 FISHERS, NY 14453-0593

MODEL NO.: TSJ150-FS-150-8-8

CAPACITY: 150

SPAN: 8'-0"

H.U.B.: 8.00 FT.

QUANTITY: 1

SHIPPING WT.: 337 LBS

DRAWN: abispr DATE: OCT 7, 2015 C.O. #: DEMOFSTSJ P/N: DEMOFSTSJ. 3A

2) DO NOT SCALE FROM THIS DRAWING.