



Installation Instructions



Buy it.

No holes to dig, no cement, and no special tools.



Place it.

Find a 30" diameter area of relatively flat space and place your mailbox. Create a flat surface if needed.



Fill it.

Open the mailbox door and remove the plastic bottom. Use a cup to fill the hollow pedestal with approximately 80 pounds of ballast. We recommend using sand or gravel. DO NOT use water.



Adjust it.

Fill the ballast to the white line in the picture above and adjust the placement of your mailbox if needed.