

## Bar Pad Installation

Thank you for running Flexx Handlebars. Once you have the Flexx Handlebars securely mounted to your motorcycle or atv, now's the time to put the finishing touches on and add the bar pad. When the pad covers are new they can be tight, so we'll show you how to install the pad so its on and on correctly.

1. Put the foam pad on the crossbars without the pad cover.

2. Take the pad cover and open it up. Take the side that has the small FASST logo (Circled in the first photo below), run that side of the pad cover through the front of the handlebar on the bottom of the foam pad. See photo below. NOTE: Installing the bar pad the opposite direction (putting the Flexx logo through the bar first) will have the Velcro seal on the front side of the bar which is prone to the wind grabbing it.



3. At this point, wrap the pad cover around the foam and start to secure the Velcro.

4. The Velcro can be difficult to fasten, especially when the pad cover is new. Stretch the pad cover (as needed) to get the Velcro to fasten at both ends of the bar pad first, and then work your way towards the center of the bar pad, making sure the Velcro is fastened securely along the way.



5. Once you have the Velcro strip securely fastened, now roll the bar pad cover so the logos are properly oriented on your bar pad. The Flexx Handlebar logos should be on the front and back of your bar pad, while the FF logo (FasstCompany/FlexxHandlebars) will be on top. If done properly, your bar pad should look similar to the photo below.

