



Simple Solution Bolt Kit Instructions

1. Insert the 10mm button head bolt through the guard as well as the 10mm bushing. The large diameter end of the bushing sits against your hand guard with the smaller side against the handlebar. Finally thread the bolt into the front of the pivot pin. Don't tighten it up yet as you need to verify the guard sits at the correct height.
2. Verify the height of your guard is where you would like it. You may need to manipulate the guards slightly to your preferred guard position. The guard is designed to sit correctly with your bars adjusted between 23-28 degrees.
3. Once you have the guards where you would like them loosen the 10mm button head bolt to apply a drop of blue Loctite and tighten the bolt. At some point when tightening the bolt the pivot pin will start to spin. You can take a punch or screwdriver, put it through the backside of the pivot pin, apply a small amount of upward or downward pressure to stop the spinning so you can snug the bolt from the front, at this point the guard should be tight against the pivot pin.