

KNEE WALL

COUNTERTOP SUPPORT BRACKET

Our Knee Wall Countertop Support Bracket is the perfect concealed countertop overhang bracket for countertop support.



THE ORIGINAL GRANITE BRACKET®

originalgranitebracket.com 888-584-1112

WATCH OUR INSTALLATION VIDEO

https://originalgranitebracket.com/pages/installation-videos

SAFETY INSTRUCTIONS

- Use the correct tools.
- Wear safety goggles & proper safety equipment.
- Follow fixture, power tools & paint manufactures instructions & user manuals.
- Use common sense & follow good construction practices.
- Consult a professional when installing brackets for load bearing application.
- Be sure the bracket has a substructure that is able to support the bracket & any other additional weight that may be added to it.
- When in doubt, consult a professional installer.

Installation Guide:

Step #1:

Measure 3"-6" from the outer edge of the cabinet, to place the first bracket. Then place brackets every 16"-20" apart for countertop protection.

Step #2:

Rout or chisel a 2.5" wide by 0.5" deep section on top of the knee/pony wall. This "pocket" will allow the bracket to sit flush with the top of the knee/pony wall.

NOTE: It is important the bracket be flush with the knee/pony wall, in order for the countertop to sit level.

Step #3:

Once the "pocket" is made in the knee/pony wall, simply insert the support bracket & screw the bracket into place making sure your screws are flush with the brackets.

NOTE: We have provided screws HOWEVER make sure the length of the provided screws are appropriate for your project. If not appropriate DO NOT use the screws provided. Each project is different so protect your project by measuring before you add the screws.

Step #4:

Using a level, make sure your brackets are level; use shims where necessary until the brackets are completely level.

Step #5:

Place your countertop on top of the cabinet & brackets.

Step #6:

Check once again that the countertop is level. Once level, caulk around the brackets with clear silicone, to hold your countertop securely in place.





