



THE ORIGINAL
GRANITE BRACKET

T BRACE

C O U N T E R T O P S U P P O R T B R A C K E T

The T Brace Countertop Support Bracket is designed to use the weight of the granite to support your countertop overhang.

The vertical tang is directly in the middle of the bracket. Once installed, half of the bracket will be inside the cabinet & half the bracket will be outside the cabinet supporting your countertop overhang.



THE ORIGINAL GRANITE BRACKET®

originalgranitebracket.com
888-584-1112

WATCH OUR INSTALLATION VIDEO

<https://originalgranitebracket.com/pages/installation-videos>

SAFETY INSTRUCTIONS

- Use the correct tools.
- Wear safety goggles & proper safety equipment.
- Follow fixture, power tools & paint manufactures instructions & user manuals.
- Use common sense & follow good construction practices.
- Consult a professional when installing brackets for load bearing application.
- Be sure the bracket has a substructure that is able to support the bracket & any other additional weight that may be added to it.
- When in doubt, consult a professional installer.

Step #1:

On the back of the cabinet, measure 6"-8" from the corner. At this measurement, cut or rout out your first 2.5" wide by 0.5" deep pocket. Make enough "pockets" to space the T Brace Brackets 16"-20" apart from each other, for maximum countertop protection.

Step #2:

Place the T Brace Bracket inside each "pocket" with the vertical tang inside the cabinet. Make sure the T Brace sits flush into the "pocket" you routed out in order for the T Brace to be flush with the cabinet wall to insure the countertop will be level & protected.

Step #3:

Once the T Brace sits flush in the "pocket" attach the T Brace to the back side of the cabinet, using the pre-drilled screw holes & appropriate wood screws.

NOTE: *It is important that the bracket be flush with the cabinet in order for the countertop to sit level & to protect the countertop.*

NOTE: *We have provided screws HOWEVER make sure the length of the provided screws are appropriate for your project. If not appropriate DO NOT use the screws provided. Each project is different so protect your project by measuring before you add the screws.*

Step #4:

Once the brackets are secured, place your countertop on top of the brackets & simply caulk around the brackets with clear silicone.

Installation Guide:

